


# RRI-BA10S3 CORDLESS ANGLE WRENCH



Edition E

Index No	Part No.	Description	Q'ty
1E	32001-WRCA(S)	Upper Housing	1
2E	32002-WRCA(S)	Lower Housing	1
3	B83WRB10	Brushless Motor Assembly ;w/driver	1
4	000-4110	O-Ring (Ø16×Ø1.5)	1
5	D51SC108B	Motor Holder	1
6	000-0242	Screw (M4×8L)	2
1C	B50WRB10	Gear Box Units	1
7	000-3128	Snap ring (RTW-28)	1
8	D39WR	Washer	1
9	D49WR10	Planet Gear	6
10	B51WR-6-1	Gear Cage Assembly	1
11	D39WR-8	Washer	1
12	B51WR-11	Gear Plate Assembly	1
13	B50WR	Gear Box Assembly	1
	(1)000-4118	(1) O-Ring (Ø28×Ø1.5)	1*
2C	B43WRB10	Clutch Units	1
14	B29WR	Clutch Assembly	1
15C	000-3854	Steel Ball (Ø7/32")	4
16	D39WR-1	Washer	1
17	D39WR-7	Washer	1
18	D48WR-1	Spring (Red)	1
19	D39WR-5	Washer (White)	1
20	D39SC108B-2	Adjust Washer	1
21	D54SC108B	Adjust Nut	1
22	000-30212I	Snap Ring (ISTW-12)	1
23	D48WR	Spring	1

Index No	Part No.	Description	Q'ty
24	B51WR	Connecting Holder Assembly	1
25	000-4120R	Marking Ring (P32, Red)	1
3D	B42WR3#BZ	Angle Housing Units	1
26	D44WR108B	Collar	1
27	D54WR108B#BZ	Lock Nut	1
28	D54WR108B-1B	Lock Nut	1
29	B49WR144B-8	Main Bevel Gear Assembly	1
30	D39WR144B	Washer	1
31	B42WR-1#BZ	Angle Housing Assembly	1
32	000-4114	O-Ring (Ø3×Ø1.5)	1
33	000-1340	Screw (M4x5L)	1
34	B49WR144B3-9	Bevel Gear Assembly	1
35	D54WR108B-2B	Lock Nut	1
36	B75WR	Sensor & LED Assembly	1
37	B09PW15-1#B1	F/R Valve (1set x 2pcs)	1
38	D48PW15-1	Spring	1
39	E76WR	PC Board	1
40	E86SC	Connector Wire	1
41	D48PW15	Spring	1
42	B09PW15#B1	Trigger Assembly	1
43	C10SC108B-2#B1	Cover	1
44D	33110-WRBA-02	Cover	1
45	000-1430C	Screw (M3xP0.5 x10L)	16
46	000-1531B	Washer (Ø3.3×Ø8)	2
50	C10WRB#B1	Cover	1
51B	C39PW15-3	Washer	1