


RRI-BA30S3 CORDLESS ANGLE WRENCH



Edition F

Index No	Part No.	Description	Q'ty	Index No	Part No.	Description	Q'ty
1E	32001-WRCA(S)	Upper Housing	1	30D	32042-WRCA-S3-01	Angle Housing Units	1
2E	32002-WRCA(S)	Lower Housing	1	27	D44WR108B	Collar	1
3	B83WRB30	Brushless Motor Assembly ;w/driver	1	28	D54WR108B#BZ	Lock Nut	1
4	000-4110	O-Ring (Ø16xØ1.5)	1	29	D54WR108B-1B	Lock Nut	1
5	D51SC108B	Motor Holder	1	30D	32049-WRBA-01	Main Bevel Gear Assembly	1
6	000-0242	Screw (M4x8L)	2		(1)33249-WRBA-13	Main Bevel Gear	1
10	B51WR-10	Gear Cage Assembly	1		(2)0-201023	Ball Bearing 96900ZZ)	3
11	D39WR-8	Washer	1		(3)0-331002	Inverted Retaining Ring(STW-10)	1
10	B51WR-10	Gear Cage Assembly	1	32D	32042-WRCA-03	Angle Housing Assembly	1
11	D39WR-8	Washer	1	(1)33242-WRCA-02	Angle Housing	1	
12	B49WR-11	Planet Gear	1	(2)0-211005	Needle Bearing (BK0609)	1	
13	B51WR-8	Gear Plate Assembly	1	33D	0-451019	O-Ring (Ø2xØ1,5)	1
14	B50WR	Gear Box Assembly	1	34D	0-121002	Screw (M3x5L)	1
(1)000-4118	(1) O-Ring (Ø28xØ1.5)	1*		35D	32049-WRBA-S3-01	Bevel Gear Assembly	1
20	D39WR-5	Washer (White)	1		(1)32049-WRBA-S3-02	Bevel Bear	1
21	D39SC108B-2	Adjust Washer	1		(2)0-201033-1	Ball Bearing (6001-2RSH)	1
22	D54WR	Adjust Nut	1		(3)0-331003	Inverted Retaining Ring(STW-12)	1
20	D39WR-5	Washer (White)	1	36	D54WR108B-2B	Lock Nut	1
21	D39SC108B-2	Adjust Washer	1	37	B75WR	Sensor & LED Assembly	1
22	D54WR	Adjust Nut	1	38	B09PW15-1#B1	F/R Valve (1set x 2pcs)	1
23	000-302121	Snap Ring (ISTW-12)	1	39	D48PW15-1	Spring	1
24	D48WR	Spring	1	40	E76WR	PC Board	1
25	B51WR	Connecting Holder Assembly	1	41	E86SC	Connector Wire	1
26	000-4120B	Marking Ring (P32, Blue)	1	42	D48PW15	Spring	1
				43	B09PW15#B1	Trigger Assembly	1
				44	C10SC108B-2#B1	Cover	1
				45D	33110-WRBA-02	Cover	1
				46	000-1430C	Screw (M3xP0,5 x10L)	1
				47	000-1531B	Washer (Ø3,3xØ8)	16
				51	C10WRB#B1	Cover	2
				52B	C39PW15-3	Washer	1