



Accessories – Maintenance kits, oils, fluids

Maintenance Kits *


Due to the uncomplicated design (two plates with compression spring, sealing of the shaft, impulse mechanism with cooling), the hydraulic impulse mechanism is reliable and easy to maintain.



Parts included in the maintenance kit: O-rings, support rings and springs for the pulse blades.*

Maintenance service

In addition to many years of experience, ZEMO has all the necessary assembly/disassembly tools and offers regular maintenance for your impulse wrenches. If you are interested, please contact us.



A vacuum pump (YEVP-1) and an oil tank (YEVP1T) are recommended for independent professional maintenance.

for type	Item No.
e-M 500	0377-0991-00-99
e-M 700	0377-0991-00-99
e-M 900	0368-0991-00-99
e-M 1100	0378-0991-00-99
RRI-30	I30RK
RRI-30 A	I30DRK
RRI-30 S	I30SRK
RRI-30 SA	I30SDRK
RRI-30 ST	IS30SRK
RRI-30 T	IS30RK
RRI-40 (X)	I40RK
RRI-40 A (X)	I40DRK
RRI-40 S	I40SRK
RRI-40 SA	I40SDRK
RRI-40 ST	IS40SRK
RRI-40 T	IS40RK
RRI-50 (X)	I50RK
RRI-50 A (X)	I50DRK
RRI-50 R	I50RRK
RRI-50 RA	I50RDRK
RRI-50 S	I50SRK
RRI-50 SA	I50SDRK
RRI-50 ST	IS50SRK
RRI-50 T	IS50RK
RRI-60 (X)	I60RK
RRI-60 A (X)	I60DRK
RRI-60 R	I60RRK
RRI-60 RA	I60RDRK
RRI-60 S	I60SRK
RRI-60 SA	I60SDRK
RRI-60 ST	IS60SRK
RRI-60 T	IS60RK
RRI-70	I70RK
RRI-70 A	I70DRK
RRI-70 R	I70RRK
RRI-70 RA	I70RDRK
RRI-70 RG	I70RGRK
RRI-70 RH	I70RHRK
RRI-70 S	I70SRK
RRI-70 SA	I70SDRK
RRI-70 ST	IS70SRK
RRI-70 T	IS70RK
RRI-80	I80RK
RRI-80 RH	IS80RHRK
RRI-80 ST	IS80SRK

for type	Item No.
RRI-80 T	IS80RK
RRI-90	I90RK
RRI-90 T	IS90RK
RRI-100	I100RK
RRI-100 T	IS100RK
RRI-130	I130RK
RRI-130 T	IS130RK
RRI-150	I150RK
RRI-150 T	IS150RK
RRI-180	I180RK
RRI-180 T	IS180RK
RRI-200	I200RK
RRI-200 T	IS200RK
RRI BIM-15 T	I40RK
RRI BIM-25 T	I70RK
RRI BIM-35 T	I70RK
RRI BIM-45 T	I80RK-YO
RRI-BIM-65 T	
TKa 60	0186-0991-00-99
TKa 70	0186-0991-00-99
TKa 80	0193-0991-00-99
TKa 90	0181-0991-00-99
TKa 110	0187-0991-00-99
TKa 120	0342-0991-00-99
TKa 140	0341-0991-00-99
TKa 150	0304-0991-00-99
Y-41	0095-0991-00-99
Y-46	0273-0991-01-99
Y-56	0259-0991-01-99
Y-61	0259-0991-01-99
Y-70	0135-0991-03-99
Y-90	0141-0991-00-99
Y-100	0334-0991-01-99
Y-130	0335-0991-00-99
Y-140	0412-0991-02-09
YBX-1	0259-0991-01-99
YBX-50	0259-0991-01-99
YBX-600 T	0189-0991-00-99
YBX-800 T	0191-0991-00-99
YED-200	0409-0991-00-99
YED-240 S	0411-0991-01-99
YEX-120	0089-0991-01-99
YEX-150	0089-0991-01-99
YEX-300 S	0086-0991-01-99
YEX-500 S	0077-0991-02-99

for type	Item No.
YEX-701	0143-0991-00-99
YEX-901	0237-0991-01-99
YEX-1400	0323-0991-00-99
YEX-1900	0320-0991-00-99
YEX-3000	0405-0991-00-99
YLa 60	0199-0991-01-99
YLa 70	0189-0991-00-99
YLa 80	0191-0991-00-99
YLa 90	0188-0991-00-99
YLa 110	0190-0991-00-99
YLa 120	0345-0991-00-99
YLa 140	0346-0991-00-99
YLT 80	0373-0991-01-99
YLT 110	0379-0991-01-99
YLT 120	0380-0991-01-99
YLT 140	0381-0991-01-99
YLT 150	0382-0991-01-99
YLTX 50	0389-0991-00-99
YLTX 60	0390-0991-00-99
YLTX 70	0391-0991-00-99
YLTX 80	0392-0991-00-99
YLTX 110	0395-0991-00-99
YLTX 120	0396-0991-00-99
YLTX 140	0398-0991-00-99
YLTX 150	0399-0991-00-99
YS-e 600	0186-0991-00-99
YS-e 800	0186-0991-00-99
YS-e 900	0181-0991-00-99
YS-e 950	0187-0991-00-99
YX-80	0095-0991-00-99
YX-180	0089-0991-01-99
YX-280	0089-0991-01-99
YX-380	0086-0991-01-99
YX-500 S(C)	0086-0991-01-99
YX-500	0077-0991-02-99
YX-700 (S)	0129-0991-00-99
YX-700 C	0281-0991-01-99
YX-900	0237-0991-01-99
YX-1100	0237-0991-01-99
YX-1400	0322-0991-00-99
YX-1900	0320-0991-00-99
YX-2400	0320-0991-00-99
YX-3000	0405-0991-00-99
YX-4500	0722-0991-00-99
YZ-N(P) 600	0186-0991-00-99

for type	Item No.
YZ-N(P) 800	0186-0991-00-99
YZ-N(P) 900	0181-0991-00-99
YZ-N(P) 950	0187-0991-00-99
YZ-T 600	0186-0991-00-99
YZ-T 800	0186-0991-00-99
YZ-T 900	0181-0991-00-99
YZ-T 950	0187-0991-00-99

Compressed-air oil

Good quality compressed air is vital for every pneumatic tool. The air must always be clean and dry and usually also lightly oiled. Low-oil tools can save up to 80% compressed air oil, which also improves the quality of the breathing air accordingly.

Before putting an impulse wrench into operation, please fill 1-3 drops of acid- and resin-free compressed air oil into the air inlet of the pneumatic tool.



Pneum./Air Oil

for type	Item No.
All pneumatic tools	353010



Hydraulic Fluid

for type	Item No.
RRI Impulse wrenches	01-0507
Yokota impulse tools	792156



Further information available 24 / 7 on our website.

* Note: The spare parts in the service kits are for hydraulic replacement only. When replacing, follow the exact filling instructions to achieve optimum performance and minimum hydraulic wear.